

## Hanging Instructions

solvoprint wallpaper  
painters canvas

### Wall surface and wall surface preparation

According to the technical guidelines for wallpapering and pasting work the surface to be covered must be dry, sound, uniformly absorbent, clean and smooth.

Remove old wallpaper and any unsound coatings completely. Close any holes or irregularities with plaster-based filler, such as Metylan GI smoothing and filling compound for indoors, and smooth the surface. In order to make absorbency consistent and reinforce old plaster surfaces or new plasterboard surfaces, prime the surface with water-based plaster sealer such as Metylan wallpapering primer for old plaster and concrete. Prime new gypsum plaster and firm, highly absorbent surfaces with diluted wallpaper paste. If the surface is smooth but not absorbent, you can make the surface compatible with wallpaper by applying a nonwoven liner with Metylan Ovalit V special-purpose wallcovering paste.

### Paste and hanging:

#### For pasting we recommend using Metylan Ovalit T.

Depending on the condition and requirements of the individual drops, **solvoprint wallpaper painters canvas** can be hung with butt joints or with overlaps using a double seam cut.

When hanging with butt joints, apply Metylan Ovalit T evenly to the surface to be covered using a roller, including a strip slightly beyond the width of the drop. Now apply the first drop of **solvoprint wallpaper painters canvas** to the bed of paste so that it is exactly vertical and press it on, eliminating any air bubbles, using a sponge rubber roller or wallpaper spreader. Then apply paste to the next length of wall surface as described above and hang the next drop so that it abuts with the previous one.

If you are going to use a double seam cut, apply Metylan Ovalit T as described above, apply the first drop to the bed of paste, again making sure that it is exactly vertical, and press it on. Then apply Metylan Ovalit T to the next length of wall surface with the roller and hang the next drop with an overlap of approx. 4 cm – 6 cm, depending on the motif and requirements, over the previous one and again press it on carefully, eliminating any air bubbles. Then make the double seam cut through the two drops using the special-purpose knife. When the strips have been cut off, join the seam.

Flatten the seam areas with a smooth seam roller. Any surplus paper can be trimmed off with a wallpaper knife along a wallpaper spreader or a straight edge.

**Different trade names Metylan Ovalit T:** France = Metylan Ovalit M

Netherlands = Perfax Wandlijm for Vinyl en Textiel

Sweden = Metylan Vatrumslim

### Note:

Prevent any emerging paste from getting onto the front or else stains and differences in gloss may occur. If paste does get onto the front of the paper, remove it immediately with a clean cloth and clean water.

A golden rule when wallpapering is to avoid heating the room too much and prevent draughts during the drying process or else seams may open.

This information only consists of general recommendations. Working conditions and wall surface conditions are beyond our influence so no claims can be based on the information. In case of doubt you are advised to conduct your own tests beforehand.